
Meridian 1

QMT21 High Speed Data Module

Description, installation, and operation

Document Number: 553-2731-107

Document Release: Standard 5.0

Date: December 1994

© 1990, 1994

All rights reserved

Printed in the United States of America

Information is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules.

SL-1 and Meridian 1 are trademarks of Northern Telecom.

Revision history

June 1989

Standard, release 1.0. This document is issued for X11 release 14.

December 20, 1989

Standard, release 2.0. This document is reissued to include updates and changes for X11 release 15.

December 20, 1990

This document is reissued to include updates and changes for X11 release 16. Updates are indicated by change bars in the margins.

December 31, 1992

Standard, release 4.0. This document is reissued to include technical updates. Due to the extent of changes, revision bars are omitted.

December 1994

Standard, release 5.0. Reissued to include editorial changes and indexing. Due to the extent of the changes, revision bars are not used.

Contents

Introduction	1
Features	2
Related documents	3
Description	5
Controls and indicators	5
Keypad dialing	5
Keypad dialing operation	5
Keyboard dialing	7
Keyboard dialing operation	7
Mode switches	7
Virtual Leased Line	9
SW1 definitions	9
SW2 definitions	10
Synchronous speeds switch	10
Function switches	11
Functional switch definitions	11
Automatic Set Relocation	12
Data Status Lamps	12
Keypad dialing from an HSDM data station	13
Miscellaneous information	13
Keyboard dialing from the HSDM data station	20
Miscellaneous information	23
HSDM troubleshooting procedures	34

Specifications	37
RS-232 interface	37
V.35 interface	37
Telephone interface	37
Synchronous mode	38
Asynchronous mode	38
Power supply	38
EIA RS-232 leads	39
CCITT V.35 leads	41
Power requirements	43
Environmental	43
Reliability	44
 Installation	 45
Hardware configuration	45
Adapter cable	45
Wire gauge setting	49
Cabling	49
DTE interface	50
Configuration	50
Field-replaceable items	51
Service change	52
Installing and removing the HSDM	52
Installation and removal procedures	52

List of figures

Figure 1	
Keypad layout	6
Figure 2	
Switch plate layout	8
Figure 3	
QMT21C switch plate layout	8
Figure 4	
High Speed Data Module Rear View	44
Figure 5	
V.35 and RS-232 socket location on the QPC824	46
Figure 6	
QMT21 with adapter cable for V.35	47
Figure 7	
QMT21 with adapter cable connection for V.35	48

List of tables

Table 1	
EIA signals supported by HSDM	39
Table 2	
V.35 CCITT signals supported by HSDM	41
Table 3	
Cabling capabilities	49
Table 4	
Field-replaceable/orderable items	51